

User's Manual




Pair ID !&\$+65535|
pair

Scan This Barcode Will Connect The Receiver




XL\$RST|
Reset




XL\$FAT|
Format Flash




XL\$AUT|
*Auto




XL\$IMT|
Immediately



XL\$IVT|
Inventory



XL\$OUT|
Data Out



XL\$DCT|
BreakThe Connect



SK00|
Missing INFO

decoder basic seting



...
1 Basic Setting



...
2 Basic Default



..04
3 Basic Serial



\$\$\$\$
4 Basic End

XL\$SET|
Setting

*All The Setting In
This Area Must Be
In State Of Setting

XXXX|
End



PT00|
*AUTO Interface



PT01|
RS-232



PT02|
KB/USB



TS00|
*OFF Function KB Transmit



TS01|
ON



BK00|
BEEP OFF Beep Tones



BK01|
*BEEP ON




CR00|
*CTS/RTS OFF Control Flow



CR01|
CTS/RTS ON



KY08|
*NOT TRANSMIT Key Word Send



KY09|
TRANSMIT



CY00|
*OFF Retransmit



CY01|
ON



0



1



2



3



4



5



6



7



8



9



CO01|
Hand Pair + 5bit



EN02|
Engine Sleep+2bit



DE00|
Char Delay +2bit




DE01|
Code Delay +2bit




CY02|
Retransmit AIM ID+5bit

Show Information



VS00|
RF Version



NO00|
Setting Status



IN00|
Self INFO



FL00|
Flash INFO



XL\$SET|
Setting



XL\$RST|
Reset



XXXX|
End

Baud Rate



BD01|
1200



BD06|
19200



BD02|
2400



BD07|
28800



BD03|
4800



BD08|
38400



BD04|
*9600



BD09|
57600



BD05|
14400



BD10|
115200

Language



SL01|
*USA



SL06|
DANMARK



SL02|
FRANCH



SL07|
JAP



SL03|
GERMAN



SL08|
SPANISH




SL04|
UK



SL09|
ITLY




SL05|
TERQ



SL10|
USER

Song / Beep



BP01|
Lower



BP06|
Short



BP02|
Middle



BP07|
*Middle



BP03|
*High



BP08|
Long




BP04|
Higher



BP09|
Longer



SL11|
UNIVERSAL



232 Stop Bit

US00|

1 bit




US02|

2 bit

Sleep Delay




PD01|
10S



PD02|
*1MIN



PD03|
5MIN



PD04|
10MIN



PD05|
30MIN

RS-232 Parity



UC01|
*NONE



UC02|
EVEN



UC03|
ODD



UD00|
*7bit




UD01|
8bit

232 Data Bit

Terminal



TE01|
NONE



TE02|
TAB(0X0D,0X0A)



TE03|
*ENTER(0X0D)



TE04|
SPACE(0X20)



TE05|
RETURN(0X0A)



UR00|

*OFF



UR01|

ON

232 BACK



XL\$SET|
Setting



XL\$RST|
Reset



XXXX|
End

Upper/Lower Case



CL00|

*General



CL01|

Shift



CL02|

Upper

NUM Lock



CL03|

Lower



NL00|

*OFF

KB Clock



NL01|

ON



KC00|

Fast (30K)



KC01|


Middle (20K)



KC02|

*Slow (10K)

Scanner RF Power



PS00|

AUTO



PS01|

*MANUAL



PS02|

1dB



PS03|

2dB



PS04|

5dB



PS05|

8dB



PS06|

11dB



PS07|

14dB



PS08|

17dB



PS09|

20dB

Receiver RF Power



PM00|

AUTO



PM01|

*MANUAL



PM02|

1dB



PM03|

2dB



PM04|

5dB



PM05|

8dB



PM06|

11dB



PM07|

14dB



PM08|

17dB



PM09|

20dB

Lock To Sleep Time



LK00|

3S



LK01|

6S



LK02|

*10S



LK03|

20S



LK04|

60S



LK05|

FOREVER

RAM



RA00|

*ON BAT TIPS OFF



RA01|

OFF



BT00|

*OFF



BT01|

ON

Engine Sleep



EN00|

OFF



EN01|

*ON

Send Beep



ST00|

*OFF



ST01|

ON

Only Data



OD00|


*OFF



OD01|

ON

Search Pair



AP00|

*SEARCH